


**Disclaimer:** For illustrative purposes only. This diagram is not specific to any airport and should not be used for navigational purposes.

50621

# AIRPORT DIAGRAM

XXX INTL (XXX)  
SOMEWHEREVILLE, USA

ATIS 123.75  
TOWER  
119.1 257.8  
GND CON  
121.9  
CLNC DEL  
121.6




JANUARY 2020  
ANNUAL RATE OF CHANGE  
0.1° W

182

SE-3, 15 MAR 2020 to 12 APR 2020

SE-3, 15 MAR 2020 to 12 APR 2020



CAUTION: Pilots are cautioned not to mistake taxiway L for Rwys 10L/28R or 10R/28L.

- Rwy 10L ldg 8800'
- Rwy 28R ldg 9189'
- Rwy 32 ldg 6503'
  
- Rwy 10R-28L S25
- Rwy 10L-28R S85, D200, ST175, DT400
- Rwy 14-32 S100, D180, ST175, DT325, DDT400

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.  
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

# AIRPORT DIAGRAM

SOMEWHEREVILLE, USA  
XXX INTL (XXX)

50621